


## IN THE BOX

Wyze Cam	x1	Quick Start Guide	x1
USB Cable	x1	Wall Plate	x1
Power Adapter	x1	Mounting Tape	x1



## SETUP


**1**  
Download the Wyze app and create an account



**2**  
Connect the camera to a power outlet and wait for 20 seconds until the yellow status light flashes



**3**  
Press the SETUP button for 3 seconds until you hear a voice prompt



**4**  
Follow the Wyze app to finish setup



## LIGHT INDICATIONS

- Solid yellow light**  
The device is powered on and initializing
- Flashing yellow light**  
The device is ready to connect
- Flashing yellow & blue lights**  
Connection is in progress
- Flashing blue light**  
The device is connected and finishing setup
- Solid blue light**  
The device is working properly

## FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

PANTONE Cool Gray 9C

## FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ISED RSS Warning

This device complies with ISED licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire d'interférence, et (2) l'appareil doit accepter toute interférence radioélectrique subi, même si l'interférence est susceptible d'en compromettre le fonctionnement.

## ISED Radiation Exposure Statement:

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux limites d'exposition de rayonnement RF ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur & votre corps. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Tous changements ou modifications non expressement approuvé par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur à opérer l'équipement.

Utilisez uniquement le chargeur fournie  
Only use the power supply provided

## NEED HELP?

- Tutorial Videos**  
[www.youtube.com/wyzelabs](http://www.youtube.com/wyzelabs)
- Troubleshooting & FAQs**  
[www.wyze.com/support](http://www.wyze.com/support)
- Community**  
[www.wyze.com/forums](http://www.wyze.com/forums)
- Contact Us**  
[support@wyzecam.com](mailto:support@wyzecam.com)  
1-844-WYZECAM



@wyzecam

WYZE CAM™  
QUICK START GUIDE