

# QUICK START GUIDE

## GET BETTER SECURITY WITH CAM PLUS

**Record Longer Videos**  
Get Event Videos with up to 5 minutes of motion.

**Smart A.I. Detection**  
Detect people, packages, vehicles, and more.


**Back-to-Back Event Recording**  
Capture more without gaps.

**Exclusive Discounts**  
Get exclusive discounts on Wyze products.

**Subscribe or learn more at [services.wyze.com](https://services.wyze.com).**

### IN THE BOX

- Wyze Cam Outdoor × 1
- Camera Charging USB Cable × 1
- Screw Assembly × 1
- Quick Start Guide × 1




Camera Charging USB Cable



Screw Assembly

### WYZE CAM OUTDOOR



- 1 Light Sensor
- 2 Lens
- 3 Microphone
- 4 Removable Magnetic Mounting Base
- 5 On/Off Switch
- 6 USB Charging Port
- 7 Status Light
- 8 Sync Button
- 9 MicroSD Slot (MicroSD card not included)
- 9 Mounting Hole

### SETUP

1 Download the Wyze app and sign in or create an account.





2 Follow the instructions in the Wyze app to set up the camera.





3 Follow the instructions in the Wyze app to mount the camera.

### WALL MOUNTING



### CEILING MOUNTING



### LIGHT INDICATIONS

#### Wyze Cam Outdoor

**Solid yellow light**  
The device is powered on and initializing

**Flashing yellow & blue lights**  
The device is pairing with the base station

**Flashing blue light**  
The device is connecting to the network

**Solid blue light**  
The device is working properly

**Flashing red light**  
The device is charging

**Solid red light**  
The device is fully charged

**No indicator light**  
The device is powered off or sleeping

### PRECAUTIONS:

- Prolonged direct sunlight can heat the inside of your camera past its maximum operating temperature of 122°F (50°C). Avoid directly sunlight where possible and only use your camera in environments within its operating temperature range: -4° to 122°F (-20° to 50°C)
- To charge your camera, plug the included micro USB cable into the USB port on your base station and connect it to your camera. Or use a power adapter and cable that will provide 5V/2A power.

### FCC WARNING:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### ISED RSS WARNING:

This device complies with ISED licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### ISED RADIATION EXPOSURE STATEMENT:

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NEED HELP?

Contact our support team:  
<https://wyze.com/support>

Join the Community:  
<https://wyze.com/community>



Scan the QR code to learn more