Wyze Light Strip Pro 10M

QUICK START GUDE

WELCOME TO WYZE

Well, hello there! If this is your first Wyze product, welcome to the Wyze family! Whether you bought Wyze Light Strip Pro to add accent lighting behind your TV, step up your social media game, or have a full on rave in your living room, you have made a great choice. Now let's get started!

IN THE BOX




SETUP

Download the Wyze app and sign in or create an account.



Den the Wyze app and tap the + sign on the top left corner of the Home tab. Tap Add Device and then select Wyze Light Strip Pro.

Select and clean the **controller's** mounting location using an included alcohol wipe. Make sure the controller can reach both an outlet and the desired location of the strips. Note: The controller must go in the middle and connect to each of the two strips. Do not try to connect the two strips together with the controller at one end.



1 Uncover the controller's adhesive backing and firmly press the controller into place. Make sure the front and side buttons will be accessible after mounting.

CONTROLLER STATUS LIGHT GUIDE

- Flashing blue & yellow In pairing mode
- Flashing blue Connecting to the Wyze cloud
- Solid blue Light strip is on

CONNECTING TO YOUR VOICE ASSISTANT

O Off

Light strip is off

Flashing yellow

Device is offline

To control your device with your voice, connect your Wyze account to Alexa or a Google Assistant.

Alexa

Dopen up the Wyze app, go into your **Account** settings, then tap on Smart Integrations to link Alexa to your Wyze account.

2 You can also link your Wyze account by asking Alexa to "Enable Wyze skill" or by enabling the Wyze skill from the Alexa app or alexa.amazon.com. If you have not downloaded the Alexa app you can download it from the App Store[™] or Google Play[™] store.

3 Once enabled, follow the on-screen instructions to link your Wyze account to Alexa. You will be prompted to enter your Wyze username and password to authorize Alexa to access your Wyze Account.

Select Add Device so that Alexa can find your device. You can also say, "Discover my devices." After Alexa finds your device, it will be listed under Devices in the Smart Home section of the Alexa app.

Google Assistant

- In the Google Home app, tap Add.
- **2** Tap Set up device.
- Tap Works with Google.
- Find the Wyze Home listing and log in with your Wyze account.
- **5** Google Assistant will automatically sync and populate a list of the devices from your Wyze account.

FCC WARNING


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Dean the desired **strip** mounting location with the included alcohol wipe and allow to drv.

Connect the strips to the controller and mount them one at a time by exposing the adhesive back and pressing the strip in place. Repeat for the second strip.

Corner Installation: If installing at a 90° angle (e.g, around the back of a TV) make a loop with the strip and reinforce each side with the included clips, as shown in the diagram below. Try to avoid bending the strip where the LED is located.



Trimming the Strip: The strip can be cut but only at the designated marks, as shown in the diagram below. Do not cut the strip except at a designated mark. Before cutting the strip, make sure the power adapter is unplugged. The trimmed portion of the strip cannot be used



D Use the included clips to reinforce the strip. Use extras around corners or where the strip bends.

B Plug the power adapter into the wall and confirm the strip is pulsing blue. If it is not, press and hold the side button on the controller for 7 seconds until the LED on the controller begins flashing blue and yellow. If the strip doesn't turn on, make sure all the connections are secure.

D Follow the instructions in the Wyze app to finish pairing the device to your Wyze account.

CAUTION

• Do not leave the device on while coiled as it may overheat.

• Avoid bending the strip where an LED is located as it may damage the product.

· Do not cut the device while it is plugged into power.

• Only mount the device onto dry, clean, and smooth surfaces.

- For indoor use only.
- Do not use if the power cord is damaged.



RF RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

ISEDC RSS WARNING

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment. This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil est conforme à la aux normes RSS de l'Industrie du Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas causer des interférences nuisibles, et (2) cet appareil doit accepter toute interférence recue, y compris les interférences qui peuvent provoquer un fonctionnement indésirable. Le fabricant n'est pas responsable des toutes interférences radio ou télévision causées par des modifications non autorisées apportées à cet appareil. De telles modifications peuvent empêcher

utilisateur d'utiliser l'appareil. Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fait partie du matériel de catégoriell) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés cidessous et avant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur

ISEDC RADIATION EXPOSURE STATEMENT

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

Cet équipement est conforme aux limites de radiations définies par IC dans le cadre d'un environnement non contrôlé. Cet équipement doit être installé et fonctionner à une distance minimum de 20 cm de votre corps.

Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and reaions

Google Assistant, Google Home, Google Play, and the Google Play logo are trademarks of Gooale LLC.

Alexa and all related marks are trademarks of Amazon.com, Inc. or its affiliates. Wyze and Wyze Light Strip are trademarks of Wyze Labs, Inc.

NEED HELP?

Contact our Support Team at: https://support.wyze.com

Join our Community: https://wyze.com/community



Scan the QR code to learn more