

<div><div><div><div>300 mm</div><div>150 mm</div><div><div><div>QUICK START GUIDE</div><div>Read this manual carefully and save it for future reference.</div><div>Disclaimer: The products, accessories, user interfaces, etc. illustrated in this guide are intended for reference only. Due to product updates, the actual product and the illustrations in this guide may vary.</div></div></div><div>150 mm</div></div></div></div>				品 牌
				型号：
				规格：
				物料编码：
				UPC：
产品名 ▶ Wyze Bird Feeder 说明书	印刷颜色 ▶ CMYK	物料材质 ▶ 105g无光铜	审核 ▶	样品
设计于 ▶ 殷方	成品尺寸 ▶ 见图示	特种工艺 ▶ 骑马订装	批准 ▶	样品数量 ▶

要求：字迹清晰，不可以有重影

QUICK START GUIDE

Read this manual carefully and save it for future reference.

Disclaimer: The products, accessories, user interfaces, etc. illustrated in this guide are intended for reference only. Due to product updates, the actual product and the illustrations in this guide may vary.

CONTENTS

IN THE BOX	1
BIRD FEEDER ASSEMBLY	3
CAMERA INSTALLATION (Wyze Battery Cam Pro)	5
CAMERA INSTALLATION (Wyze Cam v3/v4)	7
CAMERA INSTALLATION (Wyze Cam Outdoor v1/v2)	9
TREE MOUNTING	11
WALL MOUNTING	13
POLE MOUNTING	15
CORD MOUNTING	16
SUCTION CUP MOUNTING	18
ADDING FOOD	20
REMOVE THE CAMERA BRACKET	21
WARRANTY INFORMATION	22

IN THE BOX

- | | |
|---------------------------|-------------------------------|
| ❶ Wyze Bird Feeder × 1 | ❾ Pillar Connecting Piece × 1 |
| ❷ Food Tray × 1 | ❿ Cable Tie × 1 |
| ❸ Food Tray Stand × 1 | ⓫ Suction Cup × 2 |
| ❹ Solar Panel Cover × 1 | ⓬ Safety Cord × 1 |
| ❺ Camera Bracket × 1 | ⓭ Mounting Cord × 1 |
| ❻ Lens Bracket × 1 | ⓮ Screw Accessory Pack × 1 |
| ❼ L-Shaped Bracket × 1 | ⓯ Screwdriver × 1 |
| ❽ Suction Cup Bracket × 1 | ⓰ Quick Start Guide × 1 |


Note: Power Drill and 6mm drill bit required for wall mounting.




Wyze Bird Feeder



Food Tray



Food Tray Stand



Solar Panel Cover



Camera Bracket



Lens Bracket



L-Shaped Bracket




Suction Cup Bracket



Pillar Connecting Piece




Cable Tie



Suction Cup



Safety Cord



Mounting Cord



M2.5 Screws (Bag-A)



M4 Screw (Bag-B)



1/4 in Screw (Bag-C)



M4 Thumb Screw (Bag-D)



Expansion Screw Pack (Bag-E)




Male-female Fasteners (Bag-F)




Screwdriver

BIRD FEEDER ASSEMBLY

- 1 Insert the Food Tray Stand into the Food Tray and secure the bottom with two M2.5 Screws (Bag-A).




- 2 Slide the Food Tray into the main body of Wyze Bird Feeder.




3

NOTE If you have a Wyze Solar Panel, you can install it according to the diagram.

- 1 Estimate the length of cable needed to attach to the camera. Then coil the excess cable around the winding board.



- 2 Install your solar panel into the Solar Panel Cover, and mount it onto the main body of Wyze Bird Feeder as shown below.




4

CAMERA INSTALLATION


Wyze Battery Cam Pro

Wyze Bird Feeder is compatible with Wyze Battery Cam Pro, Wyze Cam v3, Wyze Cam v4, Wyze Cam Outdoor v1 and Wyze Cam Outdoor v2.

- 1 To install your Wyze camera into Wyze Bird Feeder, slide the Lens Bracket over the camera, aligning the bracket with the center of the camera lens.




- 2 Place the camera on the camera bracket, aligning it with the rear screw hole position, and tighten using an 1/4 in Screw (Bag-C).




5

- 3 With your camera installed, mount the Camera Bracket onto the main body of your Wyze Bird Feeder. Then connect the power cable to the solar panel.


Step 1



Step 2



Step 3




6

CAMERA INSTALLATION


Wyze Cam v3/v4

NOTE We recommend turning Night Vision off for this camera when using the lens bracket.

- 1 To install your Wyze camera into Wyze Bird Feeder, slide the Lens Bracket over the camera, aligning the bracket with the center of the camera lens.




- 2 Install an M2.5 Screw (Bag-A) onto the Camera Bracket (be careful not to tighten it yet), mount the camera base onto the bracket, insert it into the large hole of the camera base, pull it down to the position of the small hole, and tighten the screw.




- 3 With your camera installed, mount the Camera Bracket onto the main body of your Wyze Bird Feeder.


Step 1



Step 2



Step 3




CAMERA INSTALLATION


Wyze Cam Outdoor v1/v2

NOTE We recommend turning Night Vision off for this camera when using the lens bracket.

- 1 To install your Wyze camera into Wyze Bird Feeder, slide the Lens Bracket over the camera, aligning the bracket with the center of the camera lens.




- 2 Remove the base of the Wyze Outdoor Camera, align the front screw hole with the positioning hole of the Camera Bracket, align the rear screw hole with the second screw hole position of the Camera Bracket, place an M2.5 Screw (Bag-A) into the second screw hole position, and tighten the screw.




- 3 With your camera installed, mount the Camera Bracket onto the main body of your Wyze Bird Feeder. Then connect the power cable to the solar panel.


Step 1



Step 2




Step 3



TREE MOUNTING

You Will Need



Cable Tie




M4 Screw (Bag-B)




L-Shaped Bracket


- 1 Use the Cable Tie to attach the L-Shaped Bracket to a tree trunk or other cylindrical object.



- 2 Place Wyze Bird Feeder onto the L-Shaped Bracket.



- 3 Secure Wyze Bird Feeder to the L-Shaped Bracket with an M4 Screw (Bag-B) on the bottom of the bracket.



WALL MOUNTING


You Will Need



Power Drill



Expansion Screw Pack (Bag-E)




M4 Screw (Bag-B)




L-Shaped Bracket


- 1 At your mounting location, drill two 6 mm holes with your hand drill, then insert the Expansion tubes (Bag-E).



- 2 Position the L-Shaped Bracket over the expansion tubes, and secure with two screws.




- 3 Insert the L-Shaped Bracket into the bottom of Wyze Bird Feeder.
- 4 Secure Wyze Bird Feeder with an M4 Screw (Bag-B) on the bottom of the L-Shaped Bracket.



POLE MOUNTING

NOTE The Wyze Bird Feeder can be mounted on a pole with an outer diameter of 1 inch.

You Will Need




Pillar Connecting Piece




M4 Screw (Bag-B)

- 1 Attach the Pillar Connecting Piece to the bottom of Wyze Bird Feeder, and secure it with an M4 Screw (Bag-B).



- 2 With the Pillar Connecting Piece attached, position Wyze Bird Feeder into the pole.




CORD MOUNTING

NOTE When cord mounting your Wyze Bird Feeder, ensure it is less than 3 feet above the ground.


You Will Need



M4 Screw (Bag-B)




M4 Thumb Screw (Bag-D)




Mounting Cord

- 1 Use an M4 Thumb Screw (Bag-D) to secure the Top Cover to Wyze Bird Feeder, and use an M4 Screw (Bag-B) to secure the feeder tray to the food tray and the main body.




- 2 Hang the bird feeder at your designated location using the Mounting Cord.



SUCTION CUP MOUNTING


You Will Need




Suction Cup



L-Shaped Bracket




Male-female Fasteners (Bag-F)



M4 Screw (Bag-B)




Suction Cup Bracket




Safety Cord


- 1 Combine the L-Shaped Bracket and the suction cup bracket together, and secure both brackets using two pairs of Male-female Fasteners (Bag-F).




- ② Take two Suction Cups and remove the nuts from them. Thread the screws through the L-Shaped Bracket and the Suction Cup Bracket. Then, tighten the nuts to secure the bracket onto the glass. (Note: Ensure the side with the "Install Upward" sticker is facing upward.)



- ③ Hook one end of the Safety Cord into the middle of the camera bracket, and secure the other end of the Safety Cord to the wall.




- ④ Insert the bottom of Wyze Bird Feeder into the bracket and secure it with one M4 Screw (Bag-B).



ADDING FOOD


TIP Fill Wyze Bird Feeder with bird food before mounting.

- Open the bird feeder's top cover and pour in the food, then close.



REMOVE THE CAMERA BRACKET

- With the bird feeder removed from its mount, grasp the bottom of the camera bracket with one hand and firmly push upward.



WARRANTY INFORMATION

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at <https://wyze.com/return-warranty-policy> or request a copy by contacting Wyze at +1 (206) 339-9646.

Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions. • Google, the Google logo, Hey Google and the Hey Google logo are registered trademarks of Google LLC.

Wyze and Wyze Bird Feeder are trademarks of Wyze Labs, Inc.

NEED HELP?

Contact our Support Team:

<https://wyze.com/support>

Join the Community:

<https://wyze.com/community>



Scan the QR code
to learn more