
# QUICK **START** CIIDE Read this manual carefully and save it for future reference.

Disclaimer: The products, accessories, user interfaces, etc. illustrated in this guide are intended for reference only. Due to product updates, the actual product and the illustrations in this auide may vary.

#### INSTALLATION METHODS


Installation with adhesive tape:

Installation with screws and powered by AC wire:





Installation with screws:



Attach vour doorbell to the Back Plate:



Please Note: Install the Back Plate to the wall, then attach the doorbell. Install the doorbell less than 6.6 feet above the around. The adhesive tape only works with the Back Plate, not the Corner Kit.

## GET BETTER SECURITY WITH (+ Cam Plus

**Record Full-Length Videos** Get unlimited full-length video recordings.

Smart AI Detection Detect people, packages, vehicles, and more

Back-to-Back Event Recording Capture everything without 5-minute gaps.

Exclusive Discounts Get exclusive discounts on Wyze products.


Subscribe or learn more at mv.wvze.com.

Insert the Detaching Pin into the small pinhole at the top


Top View

To remove the camera from the Back Plate:

of the doorbell and push in.



#### PIR Sensor Pinhole 0 Lens Light Senso o \_\_\_\_\_ Type-C Microphone Doorbell Button 000 - Lens Speaker Doorbell Front Doorbell Back Indicator Speaker




## Chime Front Chime Side

### OPTIONAL CORNER KIT

Use the included Corner Kit to add 30° to the horizonta viewing angle. First, install the Corner Kit to the wall, then attach the Back Plate.



Angle (without Corner Kit)




Angle (with Corner Kit

#### LIGHT INDICATORS DURING INSTALLATION


- Solid red light The device is powered and initializing 🕌 Flashing red light The device is ready to connect
- Flashina red and blue liahts Connection is in progress
- Flashing blue light
- The device is connected and finishing setup
- Solid blue light The device is working properly

#### LIGHT INDICATORS AFTER SETUP

- Solid red light for 6s (Battery Power) Live stream is being viewed or a recording is in progress
- Pulsing blue light (Battery Power) Doorbell button pressed or motion detected
- Solid blue light (AC Power)
- The device is working properly and no operations are running



Press and hold the RESET button on the back of the doorbell for 10 seconds, or until the voice prompt sounds.



In the Wyze app, tap the + plus sign. On the Add menu, tap Device > Cameras > Wyze Duo Cam Doorbell. Follow the in-app instructions to finish setup.

#### FCC RADIATION EXPOSURE STATEMENT

#### ISED RSS WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference, (2) This device must accept any interference, including interference that may cause undesired operation of the device.

#### ISED RADIATION EXPOSURE STATEMENT

This equipment complies with ISED RE radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### WARRANTY INFORMATION

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at https://www.wyze.com/policies/refund-policy.

Wyze and Wyze Duo Cam Doorbell are trademarks of Wyze Labs. Inc.

#### CHIME SETUP

TP Press the RESET button on the side of the chime for 5 seconds, until the red light starts flashing.



>>> In the Wyze app, tap the + plus sign. On the Add menu, tap Device > Cameras > Wyze Wi-Fi Chime. Follow the in-app instructions to finish setup.

#### CAUTION

Risk of fire or explosion if the battery is replaced by an incorrect type. Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types): Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion: Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and • A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Supplier's Declaration of Conformity Unique Identifier Trade Name: WYZE Product Name: Wyze Duo Cam Doorbell Model No.: GW DBD Product Name: Wyze Wi-Fi Chime Model No.: GW\_WFCHM Responsible Party - U.S. Contact Information U.S. Company Name: Wyze Labs, Inc. Address: 8815 122nd Ave NE. Suite #201, Kirkland WA 98033 www.wvze.com/pages/contact-us

#### **NEED HELP?**

Contact our Support Team: https://wyze.com/support

Join the Community: https://wyze.com/community Scan the QR code to learn more

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

