

Read this manual carefully and save it for future reference.

QUICK START GUIDE

Disclaimer: The products, accessories, user interfaces, etc. illustrated in this guide are intended for reference only. Due to product updates, the actual product and the illustrations in this guide may vary.

GET BETTER SECURITY WITH Cam Plus

Record Full-Length Videos

Get unlimited full-length video recordings.

Smart AI Detection

Detect people, packages, vehicles, and more.

Back-to-Back Event Recording

Capture everything without 5-minute gaps.


Exclusive Discounts

Get exclusive discounts on Wyze products.

Subscribe or learn more at my.wyze.com.

IN THE BOX

Wyze Indoor Cam Pan	x1	USB Cable	x1
Mounting Kit	x1	Wall Plate	x1
Indoor Power Adapter (5V, 1.5A)	x1	Mounting Sticker	x1
		Quick Start Guide	x1



- 1 Lens
- 2 Microphone
- 3 Status Light
- 4 Setup Button
- 5 MicroSD Card Slot (Card not included)
- 6 Speaker
- 7 Power Cable

SETUP

- 1 Download the Wyze app and sign in or create an account.
 - 2 Connect the camera to a power outlet and wait for 20 seconds until the status light flashes red.
 - 3 Press and release the SETUP button, then wait 3-5 seconds until there is a voice prompt.
 - 4 Open the Wyze app and tap the + sign in the top right corner of the Home tab. Tap Add Device > Cameras > Pan and Tilt Cameras > Wyze Indoor Cam Pan and then follow the instructions.
- Only use the power supply provided.



LIGHT INDICATORS DURING INSTALLATION

- Solid red light**
The device is powered on and initializing
- Flashing red light**
The device is ready to connect
- Flashing red & blue lights**
Connection is in progress
- Flashing blue light**
The device is connected and finishing setup
- Solid blue light**
The device is working properly

LIGHT INDICATORS AFTER SETUP

- Solid red light**
Live stream is being viewed or a recording is in progress
- Quickly flashing red light**
Siren is in use
- Solid blue light**
The device is working properly and no operations are running

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Supplier's Declaration of Conformity
Unique Identifier
Trade Name: WYZE Model No.: WYZECPANL
Responsible Party --- U.S. Contact Information
US Company Name: Wyze Labs, Inc.
Address: 8815 122nd Ave NE, Suite #201, Kirkland WA 98033
www.wyze.com/pages/contact-us

NEED HELP?

Contact our Support Team:
<https://wyze.com/support>
Join the Community:
<https://wyze.com/community>




Scan the QR code to learn more

Wyze and Wyze Indoor Cam Pan are trademarks of Wyze Labs, Inc.


WALL MOUNT

- 1 Please ensure that the wall can withstand at least 4 lb of weight. Apply the mounting sticker to the wall, and mount the camera firmly to prevent damage or injury.




*Expansion tube required for installation on drywall, concrete/brick, hollow walls or walls with cavities.

- 2 Pass the power cable through the wire hole on the Wall Plate, leaving a certain length as slack. Align the slot on the base of the camera with the buckle on Wall Plate. Push the camera toward the wall until it cannot be pushed further, then gently straighten out the power cable downward.




CEILING MOUNT

- 1 Use the included mounting kit to mark the position of the holes, pre-drill the holes to be 1/4 inches in diameter and 1 3/16 inches deep.



- 2 Pass the power cable through the buckle on the upper Wall Plate, leaving a certain length as slack. Align the slot on the base of the camera with the buckle on the Wall Plate. Push the camera toward the base of the Wall Plate until it cannot be pushed further, then gently straighten out the power cable downward. To remove, pull the camera straight away from the Wall Plate.



ISED RADIATION EXPOSURE STATEMENT:

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. Only use the power supply provided. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ISED RSS-GEN 8.4 STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

ISED RSS WARNING:

This device complies with ISED licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WARRANTY

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at <https://wyze.com/return-warranty-policy> or request a copy by contacting Wyze at +1 (206) 339-9646.

Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Google Assistant, Google Home, Google Play, and the Google Play logo are trademarks of Google LLC. Wyze and Wyze Pan Duo are trademarks of Wyze Labs, Inc.

FCC WARNING:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.