QUICK START GUIDE

Read this manual carefully and save it for future reference.

Disclaimer: The products, accessories, user interfaces, etc. illustrated in this guide are intended for reference only. Due to product updates, the actual product and the illustrations in this guide may vary.

GET MORE INSIGHTS WITH Bird Watch

Bird Species Recognition
Instantly identify the birds visiting your window.

Full-Length Bird Event Videos
Get unlimited full-length bird video recordings.

60-Day Cloud Storage
Revisit your bird videos for up to 60 days.

Bird Facts & Visit Logs
Learn more about visiting birds and keep track of bird visits over time.

Subscribe or learn more at my.wyze.com.

IN THE BOX

Wyze Window Bird Cam	x 1	Indoor Power Adapter	x 1
Window Bird Feeder	x 1	Cable Clips	x 4
Mounting Sticker	x 2	Twist-Lock Suction Cups	x 4
USB Cable	x 1	Camera Positioning Template	x 1
Quick Start Guide	x 1		



FRONT



BOTTOM



BACK



SIDE

1. Lens
2. Status Light
3. SETUP Button
4. Speaker
5. USB-C Port
6. MicroSD Card Slot (MicroSD Card not included)


Bird Feeder Main Body


Seed Tray


Nectar Reservoir


Twist-Lock Suction Cups

SETUP

1. Download the Wyze app and sign in or create an account.
2. Connect the camera to a power outlet and wait 20 seconds or until the status light flashes red.
3. Single-press the SETUP button, then wait 3-5 seconds until there is a voice prompt.

Download on the App Store

GET IT ON Google Play



4. In the Wyze app, tap the + plus sign. On the **Add** menu, tap **Device > Cameras > Wired Cameras > Window Bird Cam.** Follow the in-app instructions to finish setup.

Only use the power supply provided.

Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Google Assistant, Google Home, Google Play, and the Google Play logo are trademarks of Google LLC.

LIGHT INDICATORS DURING INSTALLATION

Solid red light
The device is powered on and initializing

Flashing red light
The device is ready to connect

Flashing red & blue lights
Connection is in progress

Flashing blue light
The device is connected and finishing setup

Solid blue light
The device is working properly

LIGHT INDICATORS AFTER SETUP

Solid red light
Live stream is being viewed or a recording is in progress

Solid blue light
The device is working properly and no operations are running

WINDOW BIRD FEEDER INSTALLATION

Preparation

1. Select a glass window with a clear, unobstructed view near an indoor power outlet. Do not mount over a window screen.
2. Clean the **outdoor** glass surface thoroughly using a glass cleaner.
3. Wipe the surface dry, removing all dust, water stains, and oil stains.
4. Confirm the glass is completely dry before proceeding.

Installation Location Tips:

Squirrel-Proof: Mount the feeder at least 10 feet away from ledges, tree branches, or other structures that squirrels could jump from.
Quiet and Natural: Choose a location close to trees or plants to help birds feel at ease.
Easy Maintenance: Place the feeder above a natural surface, such as grass or soil, for easier cleanup of droppings.

Installation

Step 1: Install the Main Body

1. Remove the positioning cardboard from the twist-lock suction cups.





2. Pre-position the bird feeder. Use a level (not included) to ensure the bird feeder is straight and level. Peel off the release paper from the suction cups, then hold the main body of the bird feeder with both hands. Choose the appropriate installation height on the outdoor glass.
3. Press out the air. Position the suction cups against the glass and press firmly to squeeze out the air until the cups are fully sealed.



Squeeze out the air

4. Lock each suction cup. While maintaining pressure with one hand, tighten the outer knob of each suction cup clockwise until you feel resistance and it can no longer be tightened. This locks cup in place. After installation, gently tug on the main body to confirm it is secure.

Tighten the knob

Step 2: Insert the Seed Tray

1. Install the nectar reservoir onto the seed tray.



2. Add bird seed into the seed tray and nectar into the nectar reservoir, taking care not to overfill.

   Note: The bottom of the seed tray is equipped with drainage holes that will automatically drain water after rain.

3. Align the seed tray with the guide rails on the main body of the bird feeder.
4. Keeping it aligned, push the seed tray onto the main body until it clicks into place. This locks the seed tray in place.



CAMERA INSTALLATION

Preparation

1. Select a glass window with a clear, unobstructed view near an indoor power outlet. Do not mount behind a window screen.
2. Clean the **indoor** glass surface thoroughly using a glass cleaner.
3. Confirm the glass is completely dry before proceeding.



Installation

1. Find the included Camera Positioning Template in the packaging.
2. Align the positioning template with the lower suction cups of the bird feeder. Press to affix the sticker, centered within the viewing window.



3. Peel off the protective film from the Mounting Sticker. Align the mounting sticker precisely with the center of the positioning sticker you just applied.



4. Affix the Mounting Sticker onto the window glass, then remove the protective film from the camera lens. Press the camera firmly onto the sticker to mount it. Ensure the camera is not at an angle. Press firmly for at least 10 seconds to ensure a secure fit.



5. **Important:** Remove the Positioning Template. Once the camera is securely mounted, you must peel off the positioning template from the indoor glass. This ensures there are no obstructions around the lens.
6. Use the included cable clips to route the power cable from the window to the nearest power outlet.

ADDITIONAL NOTES

- Reapply suction cups every few months to refresh the grip. Suction can fade over time.
- The Mounting Sticker cannot be relocated or reused once placed.

WARRANTY

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at https://wyze.com/return-warranty-policy or request a copy by contacting Wyze at +1 (206) 339-9646.

FCC WARNING:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED RSS WARNING:

This device complies with ISEDC licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

ISED RADIATION EXPOSURE STATEMENT:

This equipment complies with ISEDC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. Only use the power supply provided. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity
Unique Identifier
Trade Name: WYZE Model No.: WYZECWBDC
Responsible Party -- U.S. Contact Information
US Company Name: Wyze Labs, Inc.
Address: 8815 122nd Ave NE, Suite #201, Kirkland WA 98033
www.wyze.com/pages/contact-us

Wyze and Wyze Window Bird Cam are trademarks of Wyze Labs, Inc.

NEED HELP?

Contact our Support Team:
https://wyze.com/support

Join the Community:
https://wyze.com/community

Scan the QR code to learn more