

# QUICK START GUIDE


## WELCOME TO WYZE

Hi! Thanks for getting your hands on a Wyze Plug, and if this is your first Wyze product, welcome to the Wyze family!

You just made a commitment to a better, more connected lifestyle. This guide will help you get things set up.

## IN THE BOX

Wyze Plug x 2  
Quick Start Guide x 1





## STATUS LIGHT GUIDE

Solid blue light	Flashing blue light
Connected	In pairing mode
Slow flashing blue light	Off
Connecting to WiFi	Socket power off

## SETUP

- 1 Download the Wyze app and sign in or create an account.
- 2 Insert Wyze Plug into an outlet.
- 3 The status light will flash blue to show that it's in pairing mode. If it isn't flashing blue, press and hold the Power button until it begins to flash blue.
- 4 In the Wyze app, tap the + plus sign, then Add Device > Power & Lighting > Wyze Plug. Follow the instructions in the Wyze app to complete setup.



## FCC WARNING

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ISED/RSS WARNING

This device complies with ISED licence - exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## ISED/RADIATION EXPOSURE STATEMENT

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Cet appareil est conforme aux limites d'exposition de rayonnement RF ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Ce dispositif doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur & votre corps.

## SPECIFICATIONS

**Model:** WLPP1CFH  
**Input:** 120V~, 60Hz  
**Output:** 120V~, 15A Max  
**Weather Resistance:** Indoor-only  
**WiFi:** 802.11 b/g/n, 2.4Ghz, Bluetooth  
**FCC ID:** 2ANJHWLPP1  
**IC ID:** 24984-WLPP1  
Conforms to UL Std. 60730-1  
Certified to CSA Std. E60730-1

## NEED HELP?

Contact our Support Team:  
<https://wyze.com/support>  
Join the Community:  
<https://wyze.com/community>



Scan the QR code to learn more